





NO	HARDWARE LIST		QTY
(A)		BOLTS M6x25	4PCS
(B)		WASHER Ø19xØ6x2	4PCS
(C)		ALLEN KEY M4X59	1PC

NO	PART LIST	QTY
(1)	LEG	1PCS
(2)	SEAT FRAME	1PCS


ASSEMBLY INSTRUCTION

ASHER DINING STOOL

STEP 1



STEP 2



ASSEMBLY COMPLETE

